

Maintenance Instructions Powerdaylight Products

At Techcomlight, we strive to develop our products to be as maintenance-free as possible. Nevertheless, maintenance is sometimes necessary to ensure optimal product performance and longevity.

General Maintenance

If the Powerdaylight daylight tube is installed correctly, internal cleaning of the system is not necessary. In many cases, the dome is cleaned by rainwater alone.

Only clean the product if necessary, for example in the case of visible soiling, dust accumulation or reduced light output.

Check the external product components after heavy storms, hail or prolonged drought for any damage or dirt accumulation.

⚠ Safety first! Make sure you are safe when carrying out any maintenance. Preferably use a safe ladder or work from scaffolding and avoid maintenance in bad weather.

Care Instructions

- Do not use abrasive materials. Avoid abrasive cloths, brushes and harsh detergents on all components of the system. These can damage the surfaces of the product components.
- Prevent fingerprints and grease stains. Wear gloves during maintenance to avoid contamination.
- Gently remove loose dust. Use compressed air or a dry microfiber cloth to remove dust and dirt without scratching.
- Do not use a high-pressure cleaner. Cleaning with a high-pressure cleaner is not recommended for the entire system.
Exception: The free-hanging (no ceiling) diffuser may be cleaned with a high-pressure cleaner, as long as it is done from a distance.
- Allow the system to dry gently. Let the surface air dry or gently pat dry with a clean microfibre cloth.
- Remove any green deposits from the external roof components with lukewarm water. Use a soft sponge or microfibre cloth and lukewarm water to safely remove any green deposits.

✂ Need professional maintenance?

Contact our technical service for inspection, repair or replacement parts.

Questions or need help?

Do you have any questions about the maintenance of your Powerdaylight? Visit our website: www.techcomlight.co.uk or contact us.